












TRAVERTINE WALL TILE

FEATURES AND BENEFITS

-  Please check that the wall is strong enough to take the extra load and seek professional advice if in any doubt.
-  Natural tiles need to be sealed before and after grouting in order to protect their individual finish.
-  A degree of colour or shade variation is an inherent part of these products. Please ensure that a satisfactory effect can be reached prior to installing the products as claims relating solely to colour variation or shading will not be accepted after fitting.

-  Equally stunning in both traditional and contemporary interiors.

This product can be used in the following areas:

-  Living areas
-  Kitchens and utility rooms
-  Bathrooms and cloakrooms
-  Hallways and porches
-  Conservatories
-  Light commercial
-  Outdoors

TRAVERTINE WALL TILE FIXING INSTRUCTIONS

1. Prepare

The surface to be tiled should be as flat as possible, fill cracks and when dry, sand smooth. Remove any wallpaper to leave a clean dry surface. Seal new plaster with a suitable primer.

2. Plan

Arrange tiles in the desired layout before fixing. Mix the contents of two or three packs of tiles to achieve an acceptable blend of colour and shade.

3. Fixing

Using an adhesive trowel, apply the tile adhesive, following the adhesive manufacturer's instructions. Make sure that the adhesive does not come into contact with the face of the tile. Spread adhesive onto the wall or existing tiles using a notched spreader. Place the first tile on a straight line. A spirit level will help.

Put tile spacers in between the tiles. A 6mm grout joint is recommended.

4. Sealing

Remove excess adhesive. Thoroughly clean and dry the tiles and then apply impregnator/sealer before grouting. Following the sealer manufacturers instructions. Clean and dry thoroughly before applying sealer.

5. Cutting

Natural tiles are very hard materials which we recommend cutting with a wet, diamond wheel cutter.

6. Grouting

Allow 12 hours for the tile adhesive to set before grouting. Grout the tiles taking care to ensure excess grout is removed from the surface. Clean off excess grout thoroughly with a damp sponge and dry before applying second coat of sealer.