










SLATE FLOOR TILE

FEATURES AND BENEFITS

-  Please check that the wall is strong enough to take the extra load
-  This product needs to be sealed before grouting
-  Natural stone gives an authentic and quality finish
-  Durable and hardwearing

-  Easy to clean

This product can be used in the following areas:

-  Lounge/Dining areas
-  Kitchens and Utility rooms
-  Hallways and Porches
-  Bathrooms
-  Conservatories

SLATE FLOOR TILE FIXING INSTRUCTIONS

1. Prepare

Ensure that the surface is sound, dry, flat and free from dirt grease or flaking.

2. Plan

Arrange tiles in the desired layout before fixing. Mix the contents of two or three packs of tiles to achieve an acceptable blend of colour and shade.

Position the first tile (key tile) in the centre of the room to avoid uneven gaps around the edges.

3. Fixing

Using an adhesive trowel, apply the tile adhesive, following the adhesive manufacturer's instructions.

Press tiles firmly into position, fixing all full tiles first. Use tile spacers to form even gaps.

Remove all excess adhesive from the surface of the tile before it dries.

4. Sealing

Thoroughly clean and dry the tiles and then apply impregnator/sealer before grouting.

Following the sealer manufacturers instructions.

5. Cutting

Leave tiles 24 hours before cutting and laying the edges.

Tiles can be cut to size using a wet or dry tile cutter.

6. Grouting

Allow 12 hours for the tile adhesive to set before grouting. Use the grout float to grout well into the tile joints and remove any excess immediately with a damp sponge. Allow to dry before applying a second coat of sealer.

Always follow the grout manufacturer's instructions.

Use a grout finisher to obtain a professional result. When the grout is fully dry, wipe over with a clean dry cloth.